
## **HuttView**






- Select the *Layers* widget
- Scroll down to the layer(s) you want to select, e.g. **Storm Network Assets** Group and turn it on




• Enter the property address in Address Search and zoom to it




- Click on the **Select** widget
- Turn on Enable buffer option
- Enter the buffer distance, e.g. 100
- Un-tick these layers:
  - Streetview Search
  - o Street / Bridge / Walkway / Subway Names
  - Property Address
- Turn on **Show buffer on map**




- Click on the drop-down arrow **Select**
- Choose **Select by point**




• Hover over the relevant property on the map & left-click to do the selection



- Scroll down the list until you see the selected layers (the count of selected record for each will show)
- Click the ellipses next to the layer •••
- Select View in Attribute Table




- This will open the **Attribute Table** to display the selected records visible on the map
  - If the count (bottom left) doesn't match with the selected count, zoom out until all the selected records are visible on the map.



You can export the selected records to a CSV file



• Remember to *Clear* the selection when your done.



At this stage of selecting... if you require to add or delete specific properties...

- Press the Shift key while dragging the pointer on the map to add selected features to the selection.
- Press the **Ctrl key** while dragging the pointer on the map to **remove selected** features from the selection.

These steps can be viewed in the Widget function "?" option top right of panel display for full description.